

ATmega 164P/V 324P/V 644P/V

1	PB0 /PCINT8/XCK0/T0	PA0 /ADC0/PCINT0	40
2	PB1 /PCINT9/CLKO/T1	PA1 /ADC1/PCINT1	39
3	PB2 /PCINT10/INT2/AIN0	PA2 /ADC2/PCINT2	38
4	PB3 /PCINT11/OC0A/AIN1	PA3 /ADC3/PCINT3	37
5	PB4 /PCINT12/OC0B/SS	PA4 /ADC4/PCINT4	36
6	PB5 /PCINT13/MOSI	PA5 /ADC5/PCINT5	35
7	PB6 /PCINT14/MISO	PA6 /ADC6/PCINT6	34
8	PB7 /PCINT15/SCK	PA7 /ADC7/PCINT7	33
9	RESET	AREF	32
10	VCC	GND	31
11	GND	AVCC	30
12	XTAL2	PC7 /TOSC2/PCINT23	29
13	XTAL1	PC6 /TOSC1/PCINT22	28
14	PD0 /PCINT24/RXD0	PC5 /TDI/PCINT21	27
15	PD1 /PCINT25/TXD0	PC4 /TDO/PCINT20	26
16	PD2 /PCINT26/RXD1/INT0	PC3 /TMS/PCINT19	25
17	PD3 /PCINT27/TXD1/INT1	PC2 /TCK/PCINT18	24
18	PD4 /PCINT28/XCK1/OC1B	PC1 /SDA/PCINT17	23
19	PD5 /PCINT29/OC1A	PC0 /SCL/PCINT16	22
20	PD6 /PCINT30/OC2B/ICP	PD7 /OC2A/PCINT31	21

Tab Locations

8

7

6

5

4

3

2

1

0

Moved to later date



Canceled



Done



To-Do

